

DCW Lampe Gras

SETTING THE MOVEMENT ON THE ARM

(Too hard or too soft)



Arm falls.



Use the wing nut under the base.



Screw slightly (right) to adjust the friction



Arm too tight.



Use the wing nut under the base.



Unscrew slightly (left) to adjust the friction