


# KARVEN

THE LIGHT COLLECTORS



1 Disconnect power. Use voltmeter to verify that there is no voltage present on the switch wire. Tip: Hang a card in the fuse box so no one accidentally turns on the power.

Concrete ceiling: Use a masonry drill to make a 6mm hole in the ceiling. Push a universal plug (6 mm) in the hole. Turn screw hook into the plug.

Drywall ceiling: Drill a hole of 8 mm. Push a collapsed hollow wall plug into the hole. Turn screw hook into the plug.

For all ceilings: Check with a cable locator if there are no power lines running through the place where you want to drill. Otherwise there can be a risk of short circuits. Think about your safety!

Roest products are naturally rusted and although they are thoroughly treated, Roest lighting can be scratched by sharp objects, leaving an orange marking. When this occurs, polish the scratch with Linseed oil and a cloth.

Roest products are naturally rusted and although they are thoroughly treated, Roest lighting can leave stains when it is rubbed against other materials like fabrics, wood and paper.

Ground  
Neutral  
Live

