




# LEE BROOM



## MINI CRESCENT CHANDELIER

### CONTENTS



1 X  
ALLEN  
KEY



3 X  
PLATE  
SCREWS



5 X  
CORD  
GRIP



5 X  
CORD  
GRIP NUT



1 X  
JUNCTION  
BOX



3 X  
WIRE  
NUT




5 X  
MINI CRESCENT  
PENDANTS



5 X  
E26 LED BULB



1 X  
CHANDELIER  
BASE PLATE



1 X  
CHANDELIER  
TOP PLATE

### ATTENTION

- THE MINI CRESCENT CHANDELIER MUST BE INSTALLED BY A PROFESSIONAL, QUALIFIED ELECTRICIAN.
- MINIMUM OF TWO PEOPLE REQUIRED FOR INSTALLATION.
- ENSURE POWER SUPPLY IS DISCONNECTED PRIOR TO INSTALLATION.
- THIS PRODUCT IS FOR INTERIOR USE ONLY AND SHOULD BE INSTALLED IN A DRY ENVIRONMENT.
- PLEASE USE A UNIVERSAL LEADING EDGE DIMMER SWITCH WHICH IS SUITABLE FOR THE WATTAGE OUTPUT.
- WHEN SWITCHED ON THE UNIT MAY BECOME HOT.
- BULBS ARE SUPPLIED. LEE BROOM RECOMMEND A 9W E26 2700K DIMMING LED BULB.



125W TOTAL  
MAXIMUM  
WATTAGE  
(5 X 25W)

THIS  
PRODUCT  
MUST BE  
EARTHED

110/130V  
50-60 HZ

E26  
LAMP  
HOLDER

### CARE AND CLEANING

- ONLY ATTEMPT TO CLEAN WHEN MINI CRESCENT CHANDELIER IS SWITCHED OFF.
- PLEASE ALLOW A SUITABLE COOLING PERIOD BEFORE ATTEMPTING TO CLEAN THE MINI CRESCENT OR REPLACING THE LIGHT BULB.
- ONLY USE A NON-ABRASIVE, SOFT, DRY, CLOTH WHEN CLEANING THE MINI CRESCENT CHANDELIER.

# LEE BROOM

LONDON · NEW YORK

93 RIVINGTON STREET, LONDON, EC2A 3AY +44 (0)20 7820 0742  
34 GREENE STREET, NEW YORK, NY10013 +1 212 804 8477

WWW.LEEBROOM.COM INFO@LEEBROOM.COM

## ASSEMBLY - MUST BE INSTALLED BY A PROFESSIONAL, QUALIFIED ELECTRICIAN

1. UNSCREW THE X3 SCREWS FROM THE SIDE OF THE CEILING CANOPY USING THE PROVIDED ALLEN KEY.
2. SEPARATE THE CHANDELIER BASE CANOPY FROM THE TOP CANOPY.
3. SCREW CORD GRIPS INTO THE FIVE HOLES ON THE INSIDE OF THE BASE CANOPY. FIX INTO POSITION BY SCREWING THE CORD GRIP NUTS TO THE UNDERSIDE OF THE BASE CANOPY.
4. SET PENDANT LENGTHS BY THREADING CABLE THROUGH CORD GRIPS ON BASE CANOPY.
5. SECURE PENDANT LENGTHS BY LOCKING THE CABLE GRIPS.
6. TERMINATE MAINS CONNECTION WIRES AT SUITABLE JUNCTION BOX OR BESA BOX.
7. CONNECT ALL MINI CRESCENT HOT, NEUTRAL AND EARTH WIRES INTO THE SUITABLE POINTS IN THE WIRE NUTS PROVIDED.
8. FEED MAINS WIRE THROUGH THE CENTRAL HOLE OF THE TOP CANOPY.
9. FIT TOP CANOPY TO CEILING. IT IS RECOMMENDED THAT THE CANOPY IS FITTED DIRECTLY INTO A CEILING JOIST. DIFFERENT CEILINGS REQUIRE DIFFERENT TYPES OF FITTINGS ALWAYS CHOOSE SCREWS AND RAWL PLUGS THAT ARE APPROPRIATE FOR THE SURFACE MATERIAL.
10. LIFT THE BASE CANOPY WITH THE MINI CRESCENT PENDANTS ATTACHED UP TO THE TOP CANOPY. (THIS REQUIRES X2 PEOPLE)
11. CONNECT THE TERMINATED MAINS WIRES TO WIRE NUTS. ONCE ALL WIRES ARE CONNECTED FIT WIRE NUTS INSIDE THE JUNCTION BOX.
12. A) ALIGN THE SCREW HOLES ON THE SIDE OF THE BOTTOM CANOPY WITH THE SIDE HOLES ON THE TOP CANOPY.  
B) ONCE IN POSITION USE ALLEN KEY SCREWS TO FIX.
13. FIT BULBS INTO LAMP HOLDERS. FIVE 9 WATT LED LAMPS ARE SUPPLIED. LEE BROOM RECOMMEND 9W E27 2700K DIMMING LED BULB.
14. TO CHANGE THE LIGHT BULBS ENSURE THE POWER TO THE CHANDELIER IS SWITCHED OFF AND SEE BULB REPLACEMENT INSTRUCTIONS.
15. LEE BROOM RECOMMEND THE FOLLOWING DROP HEIGHTS IN INCHES.

