




MAINE

T-3415 LC USA

493034154

Suspensión múltiple con un sólo florón. Cable textil y difusores de metacrilato en parte inferior.

Multi-pendant on a single canopy. Bottom acrylic diffusers and textile covered electrical cords.



**UL 1598 ELECTRICAL INSTRUCTIONS FOR FLUSHMOUNTS, WALL SCONCES AND PENDANTS**

SAVE THESE INSTRUCTIONS. MIN 90C SUPPLY CONDUCTORS. CAUTION -RISK OF FIRE. USE STATED WATT OR SMALLER. CAUTION-RISK OF SHOCK. DISCONNECT POWER BEFORE SERVICING. TO REDUCE THE RISK OF A BURN DURING RELAMPING, ALLOW THE BULB TO COOL DOWN. SUITABLE FOR DRY LOCATIONS ONLY. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARD INVOLVED.

**WARNING:** ALL WIRES AND WIRE NUTS USED IN THE INSTALLATION MUST BE RATED 195F (90°C). FOR INDOOR USE ONLY. THESE PRODUCT MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN.

**Atención: / Warning:**


No mirar directamente a los LED.  
Do not look directly into any LED source  
Bitte nicht direkt in die LED schauen  
Ne regardez jamais les ampoules LED directement

**Instrucciones / Assembly instructions**

1- Desenroscar los tornillos laterales del florón (A). Liberar la sujeción (B). Figura 1.

1- Unscrew the lateral screws from the canopy (A). Remove the mounting bracket (B). Figure.1


1



2- Pasar el cable manguera por el florón procurando que los agujeros queden en la parte superior (A), por uno de los agujeros inferiores de la sujeción (B) y por la brida sujetacables (C). Realizar las conexiones eléctricas asegurandose de conectar todos los cables tierra. Figura 2.

2- Insert the cable through the canopy minding that the holes are on the top (A), one of the lower holes of the mounting bracket (B) and through the cable holder (C). Connect the electrical wires. Make sure all ground wires are connected. Figure 2.

2




## Instrucciones / Assembly instructions

3- Atornillar la sujeción al techo o en la caja de conexiones (B). Figura 3.

3- Affix the mounting bracket (B) to the ceiling or the electrical junction box. Figure 3.


# 3



4- Entrar el florón (A) hasta dejarlo recto y con los agujeros alineados con los agujeros de la sujeción (B) Figura 4.

4- Insert the canopy (A). The holes must be aligned with the holes of the mounting bracket (B). Figure 4.


# 4



5- Enroscar los tornillos liberados previamente Figura 5.

5- Put the screws removed previously back in place. Figure 5.

# 5




## Instrucciones / Assembly instructions

6- Con el tornillo avellanado suministrado, atornillar la pieza (D) al techo con los pivotes en la parte inferior. Figura 6.

6- Affix the piece (D) to the ceiling using the countersunk screw provided. Please note the bottom position of the pivots. Figure 6


# 6



7- Doblar el anillo de goma (E) y sujetar el cable eléctrico en la pieza (D). Figura 7.

7- Bend the rubber ring (E). Hold the electrical wire with the piece (D). Figure 7.

# 7



8- Se pueden realizar combinaciones de hasta siete pantallas utilizando el mismo florón y los mismos conectores. Figura 8.

8- Up to seven shades can be put together using the same canopy and the same connectors. Figure 8.

# 8

