
# **BuzziProp LED**

INSTALLATION MANUAL 110V - 120V





### **Technical info**













**A** The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.


#### Excl.








### BuzziProp LED


## 2 PERS.
































BuzziSpace
Groeningenlei 141
2550 Antwerp, Kontich
Belgium

1 + 32 (0)3 846 10 00

1 info@buzzi.space
www.buzzi.space



A-000003378/02 Last update: 18/07/2019