

DCW Lampe Gras - Changing Lamp Shade



Remove Shade



Shade



Unlock the shade by turning slightly left holding top of lamp



Unscrew ring



Remove spacer



Offer shade



Push to end



Replace spacer



Screw ring, lock holding top of lamp & shade



Shade locked on