
# LEE BROOM

## ECLIPSE PENDANT LIGHT



#### CONTENTS



I x Eclipse Pendant Light

### ATTENTION! BEFORE YOU START

- Eclipse must be installed by a qualified electrician
- Ensure power supply is disconnected prior to installation
- This product is for interior use only and should be installed in a dry environment only
- Please read the instructions carefully before you commence install

### ASSEMBLY - please see associated diagrams overleaf

- TERMINATE ALL MAINS WIRES BEFORE INSTALLATION
- DO NOT REMOVE THE DRIVER SUPPLIED
- I. Create one suitable hole in the ceiling positioned exactly where the electrical power supply is located for the pendant light. The hole in ceiling is to house the LED driver. Ensure hole is big enough to fit the LED driver but not so big that the ceiling plate cannot be securely fixed.
- Separate the back plate from the ceiling plate cover by unscrewing the end nut.
- Open the cover on the connector block junction box to access the terminals.
- 4. Connect mains power to the connector block terminals. Use the cable insulation sleeve provided.
- 5. Close cover on the connector block junction box.
- 6. Position junction box and LED driver in the hole in the ceiling.
- Mount the back plate to required position on the ceiling.
  Always use the appropriate fixings for the ceiling material.

- 8. Set the desired drop height of the pendant. Pass the tensile wire up through the cable glider to raise the pendant light. To adjust pendant light lower, support the full weight of the pendant light, depress the nozzle of the cable glider and pass the tensile wire down.
- To adjust length of electrical cord, loosen screw on cord restraint and pass electrical cord through cord restraint.
   Tighten screw on cord restraint at desired length. Allow some slack in electrical cord so that full weight of pendant light is supported by the tensile wire.
- Reattach the ceiling plate cover by threading the end nut into the back plate.


#### CARE AND CLEANING

- Only clean when Eclipse is switched off
- Please allow a suitable cooling period before cleaning
- Only use a non-abrasive, soft, dry cloth when cleaning Eclipse

For more information please contact:

US & Canada Inquiries: +1 212 804 8477 - 34 Greene Street, New York, NY 10013 - sales@leebroom.com UK & Global Inquiries: +44 207 820 0742 - 95 Rivington Street, London, EC2A 3AY - info@leebroom.com WWW.LEEBROOM.COM





For more information please contact:

US & Canada Inquiries: +1 212 804 8477 - 34 Greene Street, New York, NY 10013 - sales@leebroom.com UK & Global Inquiries: +44 207 820 0742 - 95 Rivington Street, London, EC2A 3AY - info@leebroom.com WWW.LEEBROOM.COM

