
## Beadlight BE/JET/WM



The lamps cannot be changed in the luminaire.

